


E	(○○○)	B	2 SC 828	C	(○○○)	E	BC 238	C	(○○○)	B
			2 SC 829				BC 328			
		C	2 SC 1047				BC 338			
			2 SC 1359				BF 314			
			2 SC 1406							
			2 SA 751							

Transistoren · Dioden

Position	Typ	Franz T
T 1	2 SC 1359 B	RF 314
T 2	2 SC 1047 C	RF 314
T 3, T 7	2 SC 829 C	RF 241
T 4	2 SC 1359 B	RF 241
T 5	2 SC 829 B	RF 241
T 6	2 SC 829 B	RF 940
T 8, T 9, T 10	2 SC 828 R	BC 258
T 11	2 SC 1406 R	BC 338
T 12	2 SA 751 R	BC 398
T 13	2 SB 324 H	1 N 400
D 1, D 2, D 5, D 7	1 S 2078	1 N 414
D 3	1 S 2638	-
D 4, D 6, D 8, D 9, D 10	1 N 60	A A 112
D 11	KB 265	-
D 12	WZ 054	BZY C 6
GR 13	B 20 C 275	-
D 14	MR 9601	-



UKW - Taste gedrückt
Tastensatz von der Lötseite gesehen





Fig. 9.16 Schema elettrico della radio portatile Partner 400 della Telefunken.